

Red = 12V switched
Black = Ground
Green = Signal*

*Signal can come from
MSD tach port or distributor
(-) side of coil.

Notes:

1. Install jumper in factory
tachometer connector to
complete ignition (+) circuit
to coil.

2. OEM tach wiring may be
used as 12V power source.

