


REMOVAL AND INSTALLATION

Quarter Panel Speaker



Item	Part Number	Description
1	W709996	Quarter panel speaker screws (4 required)
2	18808	Quarter panel speaker
3	14A005	Quarter panel speaker electrical connector
4	W701930	Quarter panel speaker mounting bracket screws (3 required)

Removal and Installation

1. Remove the quarter trim panel. For additional information, refer to Section 501-05.
2. Remove the 4 screws and the quarter panel speaker.
  - Disconnect the electrical connector.
3. To install, reverse the removal procedure.